

# Eco Dipper

## Low Cost Device ideal for Environmental Sampling

Suitability: Low viscosity liquids

Material: Polypropylene (PP)

Type: Single Point or Cross Sectional

Operation: **Technique 1 - Point Sampling**  
Close valve on top of sampler. Insert the sampler to the point where the sample is to be taken. Open valve and wait several seconds to allow the sample to flow in. Close the valve. Remove Sampler.

**Technique 2 - Cross Sectional**

Open the valve on top of sampler. Insert the sampler into the product. Product will enter the sampler as it is pushed through the product. Close the valve. Remove Sampler.



### Extendable

The 2000mm long sampler is extendable between 1100mm and 2000mm



**Discharge** - Turn valve so that sample can be deposited into collection container



**Valve** - Simple to operate - just turn handle



Note: Eco Dippers can not dismantled - it is therefore very difficult to clean the interior

Part No.	Length	Diameter
5000A-500	500mm	22mm
5000A-1000	1000mm	22mm
5000A-2000	2000mm*	22mm