

Etch-It™

Crevice Free GMP Marking System



Sampling Systems's Etch-It system is the ideal way to permanently mark both stainless steel and aluminium.

Hygienic, GMP correct, crevice free etchings can be done in seconds.

Etching Masks and Etching Paper

An Etching Mask is required as a template for your text.

Etching Masks can be quickly and easily made using the Etch-It printer. These masks can be used up to two or three times.

1. Make an Etching Mask



Produce your own etching masks quickly and easily. Simply design the text you require printing, size and print it straight on to the etching paper.

- Range of font types and sizes
- Quick and easy to use
- Simple paper loading
- Requires 230v 50Hz electrical supply or 8 x Batteries Size AA (R6) - not supplied

2. Etch



1. Plug In the leads



2. Attach Lead on item that is to be etched



3. Place the Etching Mask and apply the etching fluid using the Electrolyte Applicator



4. Clean etching area thoroughly using demineralised water

Part No.	Description
8096A-1	Etch-It Starter Kit containing: 1 x Etch-It power unit (requires 230v 50Hz) 1 x Roll of etching paper 1 x Bottle of etching fluid - 1000ml 1 x Set of leads for attaching to equipment to be etched 1 x Electrolyte Applicator 1 x Etch-It printer (requires 230v 50Hz or 8 Batteries size AA (R6) - not supplied)
Spares:	
8096A-2	Roll of etching paper (3m per roll)
8096A-3	Bottle of etching fluid - 1000ml

Please contact us for special custom made, high quality Etching Masks that can be repeatedly used.



Please contact us to discuss if you have any questions