

No Cleaning — No Cross Contamination — Reduce Costs

Disposable Sack Sampler

The Disposable Sack Master is a hygienic, single use device that has been specially designed to take samples through the side of a sack.

All Disposable Sack Masters are individually bagged and for special applications the device is available pre-sterilised.

- Suitability:
- Powders and granules
- Features:
- Single point sample
 - Individually wrapped
 - Made from tough HDPE (FDA acceptable grade - conforms to CFR177.1520)
 - ATEX rated for zones 0, 1 & 2
- Options:
- Available pre-sterilised

**ATEX Rated
Zones: 0, 1 & 2**



Unwrap Sampler



Insert the sampler through the side of the sack.

Angle sampler downwards to allow the product to flow into the sample collecting bag



Seal hole with a UA label (See Page 80 for details of our range of UA Labels)



Part No.	Length	Diameter	Pre-Sterilised	Quantity per Box
8085A-100	400mm	25mm	No	100
8085A-100S	400mm	25mm	Yes	100
8080A-540	Sample Collecting Bag 540ml - for hygienic use. Sterile		Qty: 500 bags	
8080A-810	Sample Collecting Bag 810ml - for hygienic use. Sterile		Qty: 500 bags	

Discounts Available for Bulk Orders or Yearly Contracts