

PeriPump

Powered Liquid Sampling - Ideal for Sampling From Depth

The PeriPump allows samples of liquids and suspensions to be quickly taken. At the heart of the system is a battery powered peristaltic pump. The pump does not get wet during operation.

1. Easy to clean - the liquid only comes in contact with the hose
2. Liquid is pumped directly into sample bottle
3. Use at depths of up to 5m (Note: this is product dependent)
4. Delivery rate - up to 3L/min

Highly effective and yet
simple & easy to use

What's in the Box?



The PeriPump Sampling Set includes:

- Pump & Drill
- Rechargeable battery
- Battery Charger*
- Bottle Holder for 250ml bottle
- Suction Hose - 5m length - made from PVC
- Plastic carrying case

* The battery charger is suitable for use with a 230v 50Hz supply. Special chargers for other voltages are available, please ask for details



Part No.

Description

5640A-01 PeriPump Sampler Set (see box above for details)

Spare Suction Hose

5640H-100 Suction Hose - 100m length - Made from PVC

5640M-1 Suction Hose - 1m length - Made from Marprene®

Sample Collecting Bottles

8105B-250 Sample Collecting Bottle - 250ml - HDPE - Box of 100 bottles

8105B-500 Sample Collecting Bottle - 500ml - HDPE - Box of 100 bottles

8105B-750 Sample Collecting Bottle - 750ml - HDPE - Box of 100 bottles

Spares

85640S-01 Bottle holder for 250ml and 500ml bottles

